HOME | ABOUT US | CAREERS | LITERATURE | CUSTOMER SERVICE | ENGLISH | SEARCH

ODUCTS | SERVICE PARTS | BIM-REVIT | CONTACT | WHERE TO BUY

COMMERCIAL WASHROOM INNOVATION

Advocate Soap Recommendations

Soaps and Maintenance

The info below serves as a quick overview for Advocate Lavatory soap recomendations, see the Soap Recommendation document for more technical information

Recommendations

- Use Thinner Soaps viscosity <2500 cPs is required to ensure adequate flow. Soaps >2500 cPs may either
 decrease flow or clog the dispenser.
- Dilute Soap Concentrate Many soaps are sold in concentrate form and should be diluted with water before
 filling the dispenser.
- Prime The Dispenser The soap line will need to be primed during first installation and any time the tank is completely emptied.
- Refill When Indicator Flashes Red This tells you the soap is almost empty and should be refilled. The
 dispenser should not need to be primed in this case.

Compatible Soaps

Brand Compatible Model Viscosity (cPs) approximate*

Brand	Compatible Model	Viscosity (cPs) approximate
Aterra	12079	1403
Boardwalk White Lotion Soap	BWK420	1600
Champion	02422 or 02459	77
Deb SBS 72	72105	130-200
Earth Friendly Products	PL9664/04	580
Kutol Job/Antiseptic Lotion Soap	2507, 2509	1850
Maintex (HomeDepot)	A50	350
Nyco	e.logic/e.free	1433
Nyco	Pink-EC	1367
Nyco	Nyco White lotion	1400
PCS Industries	PS200-1	633
Spartan	3003, 3006	130
Stoko Estesol Classic	28331704	2000
Zep Professional	R05224	780

Additional Compatible Soaps

Models manufactured after 11/20/14 ONLY - (blue soap supply tube, black elbow)
Thes models can handle soaps up to 6,000 cPs, but may dispense a less than ideal ammount.

Brand Compatible Model Viscosity (cPs) approximate*

Brand	Compatible Model	Viscosity (cPs) approximate
Betco Winning Hands Antibacterial	14104-00	2500-5000
Betco Winning Hands Pink Lotion	11204-00	3000-5000
Betco Winning Hands Premium Antibacterial	73604-00	2500-5000
Betco Winning Hands Ultra Mild Antibacterial	74404-00	2500-4000
Boraxo	DIA 02709	2900
Deb SBS 61	61103	3000 - 5000
Deb SBS Splash	7105	3000 - 5500
Dial Basics	6047	2500 - 4500
Inopak Enrich Pink Lotionized Soap	5011-420-02	4000
Inopak Style Antibacterial Liquid Soap	5031-420-02	5100

Kutol 550 Pink Pearled Lotion Soap	2407, 2409	3500
Kutol Fragrance Free Dye Free Soap	6809	3500
Kutol HealthGuard/Antibacterial	5009	5000
Kutol Lotion Velvet Hand Soap	2607, 2609	3500
Liquid Dial Gold Antimicrobial Soap	88047	3000 - 6000
WhiskCare 365, Premium Antibacterial	WC-365-SN-4	2000 - 4000
WhiskLotion 120, All Purpose Soap	WL-120-SN-4	3000 - 5000

^{*} Viscosity verified through manufacturer's MSDS. Formulas are subject to change.

Other soaps will be added here as they are tested.

Priming The Soap Dispenser (Models manufactured prior to 2/1/14)

The first time you use the soap dispenser, it will need to be primed. It may need to be primed again if you're refilling an empty tank of soap.

- 1. Pour 1 cup of water into the tank
- 2. Put hand under soap spout to activate dispenser. Repeat until water comes out.
 - Soap activates up-to 3 times within 15 seconds
 - After 3 activations, dispenser will not activate during 15 second, anti-vandal, timer. Dispensing will
 resume thereafter
 - It will take 8-12 activations to prime the line
- 3. Once system is primed, pour in compatible soap until full (indicated by "chirp" sound)

Priming The Soap Dispenser (Models manufactured after 2/1/14)

The first time you use the soap dispenser, it will need to be primed. It may need to be primed again if you're refilling an empty tank of soap.

- 1. Pour 1 cup of water into the tank
- 2. Put hand under soap spout for 15 seconds to activate auto prime mode
 - Hold hand in place for up to 30 seconds
 - It will take 8-12 activations to prime the line
- 3. Once system is primed, pour in compatible soap until full (indicated by "chirp" sound)
- * If you are unsure of manufacture date try both methods to prime the unit





Designed for convenience and durability

Lavatories

Safety Fixtures

The best coverage on the market





Showers







Hot Water. On Time. Every Time

Ligature Resistant

Designed to minimize ligature points







ABOUT BRADLEY CUSTOMER SERVICE ANSWERNET

^{*} If you are unsure of manufacture date try both methods to prime the unit